



70 HARTWELL ST., WEST BOYLSTON, MA 01583
www.curtiscab.com

CURTIS CLIMATE CONTROL™ 48V OVERHEAD HEATER CONSOLE INSTALLATION INSTRUCTIONS

E-Z-GO TXT

48 Volt Electric Models Only
Heater Unit Only - p/n 1HAP2
TXT Mount Kit with Hardware - p/n 1HAP2-TXT

**The contents of this envelope are the property of the owner.
 Be sure to leave with the owner when installation is complete.**



DANGER!

Battery—Explosive Gases. Do not smoke. Keep sparks and flames away from the vehicle and service area. Service only in a well ventilated area.

Battery—Poison! Contains acid! Causes severe burns! Avoid contact with skin, eyes, or clothing. Wear a full face shield and rubber gloves when working on or near batteries. If contact occurs: External—Flush with water. Call physician immediately.

Internal—Drink large quantities of milk or water. Follow with milk of magnesia or vegetable oil. Call physician immediately.

Eyes—Flush with water for 15 minutes. Call a physician immediately.

WARNING!

~~Only trained technicians should service or repair the unit. Anyone doing repairs or service~~ should have knowledge and experience in electrical and mechanical repair. The appropriate instructions must be used when performing maintenance, service, or installation.

Follow the procedures exactly as stated in these instructions, and heed all DANGER, WARNING, and CAUTION statements both in this instruction manual as well as those posted on the vehicle.

Prior to servicing the vehicle, turn the key switch to OFF, move the tow/run switch under the seat to the tow position, and set the parking brake.

Always wear safety glasses or approved eye protection when servicing the vehicle.

Moving parts! Do not attempt to service the vehicle while it is running.

Hot! Do not attempt to service while motor is hot. Failure to heed this warning could result in severe burns.

Use insulated tools when working near batteries or electrical connections. Avoid shorting components or wiring.

If wires are removed or installed, make sure wiring and wire harness are properly routed and secured. Failure to properly route and secure wiring could result in vehicle malfunction, property damage, personal injury, or death.

If necessary to lift the vehicle, lift only one end of the vehicle at a time. Use a suitable lifting device (chain hoist or floor jack) with 1000lb. minimum lifting capacity. Be sure to chock the wheels that remain on the floor when lifting and also to set the parking brake. Do not use the lifting device to hold the vehicle in raised position. Use only approved jack stands of proper weight capacity to support the vehicle.

Curtis Climate Control: E-Z-GO TXT

TOOLS REQUIRED:

OPEN END WRENCHES (METRIC AND SAE)
RATCHET AND SOCKETS (METRIC AND SAE)
ALLEN WRENCHES (METRIC AND SAE)
SCREWDRIVER (PHILLIPS HEAD)
ELECTRIC DRILL AND 6" PHILLIPS HEAD BIT


DRILL BITS - 7/32", 5/16" & 1/2"
TAPE MEASURE
SCISSORS
FINE POINT ERASABLE MARKER

STANDARD PARTS INCLUDED


OVERHEAD HEATER CONSOLE		
p/n	Description	Qty/Unit
1HAP1A	Heater Unit Only*	1
1HAP1B	2 Speed 12V Fan Only	1
1HAP1C	3 Switch Panel	1
1HAP1D	2" Round 360° Vent	3
1HAP1E	Dome Light	2
1HAP1F	On/Off Dome Light Switch	1
1HAP2-TXT	TXT Mount Kit with Hardware	1

* Difficult to install – call Curtis before ordering
(800) 343-7676


Hardware Kit (1HAP2-HWK)	
Description	Qty/Unit
10-32 x 3/4" Phillips Head Bolts	6
10-32 x 1-1/2" Phillips Head Bolts	6
10-32 Nylon Locknuts	4
#10 SAE Flat Washers	8
#8 x 3/4" Sheet Metal Screws	6
#8 x 1-3/4" Sheet Metal Screws	2
#10 x 3/4" Self Drill/Tap Screws	12
1/4-20 X 1-1/2" Hex Head Bolts	4
1/4-20 Nylon Locknuts	4
1/4" SAE Flat Washers	4
1/4" Steel Fender Washers (1" OD)	4
1/4" Rubber Fender Washers (1" OD)	4
3/8" Thick Nylon Spacer (>1/4" ID, 1/2" OD)	2
3/4" Thick Nylon Spacer (>1/4" ID, 1/2" OD)	2
1" Thick Nylon Spacer (>1/4" ID, 1/2" OD)	2
P-Clip, 1/2" Diam. X 3/8" Wide Plastic	8
8" Zip Ties	6



Heater Mount 3
(HAP2M-3)



Heater Mount 4
(HAP2M-4)



Heater Unit
(1HAP2)

1. VEHICLE PREPARATION

- 1.1 Read and understand all instructions before beginning installation.
- 1.2 Make sure batteries are fully charged and in good condition before installing the Curtis Climate Control overhead heater console.
- 1.3 Move the run/tow switch located under the seat to the tow position.

2. Heater Installation with StreetPro SE Cab

2.1 Per fig. 2.1, attach the Heater Mount 4 to the front of the heater unit using two 10-32 x 3/4" long Phillips head bolts. Tighten both bolts.

2.2 Per fig. 2.2, mark the center of the vehicle from side to side on the bottom surface of the front roof support tube. Then mark hole locations 1-1/4" to either side of center mark, centered on the tube front to back.

2.3 Per fig. 2.3, orient heater unit with heater mount as shown. With someone supporting the back, line up the holes in the mount with the marks made in the previous step. Attach with two #10 x 3/4" long self-drilling/tapping screws using a drill, taking care not to over-tighten and strip out the threads.

2.4 With the back of the heater unit still supported, install four #8 x 3/4" long sheet metal screws through the four holes shown in fig. 2.4 and into the ribs in the roof. CAUTION: these thread into plastic. Do not over-tighten. Over-tightening may damage the plastic threads and cause them to strip out.

2.5 Route wire harness rearward along upper frame tube on cab as shown in fig. 2.5. Use zip ties and p-clamps with #10 self drilling/tapping screws to attach to roof support tube.

2.6 Per fig. 2.6, continue routing harness along upper frame tube, over the top pivot mount, down the rear frame tube on the cab and under the seat. Use p-clamps with #10 self drilling/tapping screws to attach to frame tube. Caution: take care not to pinch the harness between the cart's seat and body and damage the wires.




Figure 2.1 (side view of heater unit front)




Figure 2.2 (view from front of vehicle)




Figure 2.3 (view from front passenger's side)




Figure 2.5 (view from passenger's side)




Figure 2.4 (view forward from center of seat)

Curtis Climate Control: E-Z-GO TXT

3. Heater Installation without StreetPro SE Cab

3.1 Per fig. 3.1, attach the Heater Mount 3 to the front of the heater unit using two 10-32 x 3/4" long Phillips head bolts. Tighten both bolts.

3.2 Per fig. 3.2, mark the center of the vehicle from side to side on the bottom surface of the front roof support tube. Then mark hole locations 1-1/4" to either side of center mark, centered on the tube front to back.

3.3 Per fig. 3.3, orient heater unit with heater mount as shown. With someone supporting the back, line up the holes in the mount with the marks made in the previous step. Attach with two #10 x 3/4" long self-drilling/tapping screws using a drill, taking care not to over-tighten and strip out the threads.

3.4 With the back of the heater unit still supported, install four #8 x 3/4" long sheet metal screws through the four holes shown in fig. 3.4 and into the ribs in the roof. CAUTION: these thread into plastic. Do not over-tighten. Over-tightening may damage the plastic threads and cause them to strip out.

3.5 Route wire harness forward and down the front roof support tube on cab as shown in fig. 3.5. Use zip ties to attach to roof support tube.




Figure 3.1 (side view of heater unit front)




Figure 3.2 (view from front of vehicle)



Figure 3.3 (view from front passenger's side)



Figure 3.5 (view from passenger's side)




Figure 3.4 (view forward from center of seat)

3. Heater Installation without StreetPro SE Cab (cont'd)

3.6 Per fig. 3.6, continue routing the wire harness down the roof support tube and under the fender. Note: you can drill a 1/2" hole in the body panel and route the wire harness through and inside the fender. **CAUTION: before drilling, make sure there is sufficient clearance underneath the fender.**

3.7 Per fig. 3.7, route the wire harness under the floor board through the existing cut-outs in the vehicle frame and up into the battery box area under the seat. Secure with zip ties, p-clamps and #10 self-drilling/tapping screws. Note: make sure harness is secured and not the lowest point to prevent wire pinching/snagging on obstacles.




Figure 3.6 (view from driver's side)




Figure 3.7 (view from passenger's side)

4. Heater Wiring

Danger! Batteries: Follow warnings listed in instructions and on vehicle.

Note: This heater unit is **only for 48 volt systems**. Using in any other systems can damage the unit and result in injury.

Note: It is recommended to use a 48V DC to 12V DC Converter to provide proper voltage and to distribute the load required to run the heater unit fan and lights over all the batteries. The TXT DC Converter Kit (E-Z-GO p/n 605967) is available from E-Z-GO. See fig 4.2.




Figure 4.2 (E-Z-GO DC Converter Kit)

For all 48 volt battery configurations:

Warning: Confirm all voltage outputs with a volt meter before connecting to heater unit.

4.1 Connect the black wire (ground) of the heater unit to the negative terminal on the first battery.

4.2 Connect the red wire (12V) of the heater unit to the positive 12V terminal on the DC converter in fig. 4.2.

4.3 Connect the yellow wire (48V) of the heater unit to the positive terminal on last battery.

4.4 Switch the run/tow switch back to run.

Curtis Climate Control: E-Z-GO TXT

USER NOTES:

The Curtis Climate Control overhead heater has been designed to provide an instant heat source on those less than perfect days, and a nice cool breeze on the perfect ones.


OPERATION:

HEAT: The heat switch operates the heating element and must be used in conjunction with the fan speed switch to select the amount of air required to defog the windshield or heat the cab.

FAN: The high output 12v fan provides two speeds of cool breeze when it's operated with the heat switch in the off position.

AUX: The auxiliary switch (AUX) is a 12v power source that is pre-wired and can be used for a strobe light, etc.

INTERIOR LIGHT: To turn the lights on, use the rocker switch located on the underside of the unit next to the driver's side dome light.



CARE AND MAINTENANCE

Check and tighten hardware after 40 hours of operation.

Periodically inspect and tighten hardware for the remainder of the unit's service life.

QUESTIONS AND COMMENTS

Questions or comments regarding this heater should be referred to your local golf car dealer.

When calling, please have your dealer number, vehicle model, part number, and quantity available.

For service parts, contact: Curtis Industries, LLC.
Phone: 1-508-853-2200 Fax: 1-508-854-3377

www.curtiscab.com
E-mail: info@curtiscab.com