

## Wiper Arm Installation Update for Standard wiper arm p/n: 9PWA14/16 or Pantograph wiper arm p/n: 9PWA18-PGS

Wiper arms can be supplied in different configurations. All will have set screws, but not all will have spring clips. Set screws are the latest version and spring clips are being phased out. The wiper arms are supplied with one or two set screws (depending upon the arm style). Before fully pressing the wiper arm deeply and fully onto the splined shaft of the wiper motor, make sure the full window sweep is agreeable by cycling the wiper motor on for one full sweep pattern. Once satisfied that the sweep is good, fully seat the wiper arm onto the splined shaft of the wiper motor then tighten the one or two set screws provided (2 foot-pounds max. torque). Ref.: the M5 set screws require a 2.5mm Allen wrench.

