



**POLARIS®**

DOOR INSTALLATION INSTRUCTIONS

POLARIS MODULAR STEEL DOORS (p/n 2875934-067)

**IMPORTANT: THIS ACCESSORY WEIGHS
94 POUNDS. PLEASE ADJUST THE VEHICLE
PAYLOAD ACCORDINGLY.**

**The contents of this envelope are the property of the owner.
Be sure to leave with the owner when installation is complete.**



**NOTE: You must have the following to complete the installation of these doors:
Windshield Assembly (p/n 2874886), Rear Panel Assembly (p/n 2874888),
and Roof (p/n 2874887).**

1. INSTALL DOORS

NOTE: If pin hinges are not installed on rear panel, remove rear panel and install pin hinges with the pin toward the front. Reinstall the rear panel.

- 1.1 Install doors onto pin hinges. Work the doors back and forth until the hinges are completely seated.
- 1.2 Remove the two (2) 5/16" button head screws in the side of the front windshield assembly and lower mount. Install striker pin and mount to the inside of the lower mount as shown in fig. 1.2. (NOTE: finger guard to end up being centered and facing inwards.) Repeat for opposite side.





Fig. 1.2

POLARIS MODULAR CAB PARTS LIST**STEEL DOOR KIT P/N 2875934-067****HARD SIDED DOORS**

QTY.

P/N


LEFT	1	2875934-067LD
RIGHT	1	2875934-067RD

**STRIKER PIN****MOUNT ASS'Y.**

QTY.

P/N



2	2874889-2
---	-----------

* LONG STRIKER BOLT
(9DL01J)**GAS SPRING MOUNTS**

QTY.

P/N

2	2875934-067GSM
---	----------------

**RUBBER TYPES:****ADDITIONAL SERVICE PARTS**

P/N	DESCRIPTION
9PH006	UNITIZED FRAME HINGE KIT-LH
9PH005	UNITIZED FRAME HINGE KIT-RH
9SW-C2L	LEFT DOOR SLIDER ASSEMBLY
9SW-C2R	RIGHT DOOR SLIDER ASSEMBLY
9DL03A	ROTARY DOOR LATCH W/ HANDLE -LH (SHORT)
9DL03B	ROTARY DOOR LATCH W/ HANDLE -RH (SHORT)
9DL01C	OUTSIDE R-LATCH HANDLE W/KEY
9GS02	GAS SHOCK (DOOR) (SINGLE)