



Kioti CK Series cab on Bobcat CT2025 HST, 2035 HST, OR CT2040 HST (Modifications Required)

- 1 Relocate loader hydraulic quick connects forward to make clearance for the cab by drilling new holes in the mounting bracket as shown below.





- 2 If necessary, drill a new 1-1/8" dia. hole in cowl to route heater hoses around loader hydraulic lines. Locate hole directly above the existing inboard hole as shown. Plug—cover outboard hole not used.

