P. 1 of 11

Club Car Carryall Driving Range Enclosure p/n: 47587415002 compatible with Carryall models 300, 500, and 700

The contents of this manual are the property of the owner. Be sure to leave with the owner when installation is complete.



APPROXIMATE INSTALLATION TIME: 3 hours for full cab (not including accessories)

BEFORE YOU START:

- Read and understand all instructions before beginning.
- To assist with the cab installation, leave all bolts loose for later adjustment unless otherwise specified.
- Use caution to avoid damaging the factory installed threaded inserts. Begin the bolt engagement by hand to guard against potential cross threading.

Tools Required:

- T40 Torx driver
- Ratchet with 3/8", 7/16", 1/2" and 9/16" sockets
- (Optional) Air or electric powered socket driver

NOTE: Powered driver is not recommended for bolts into threaded inserts in the roof and rear frame.

- 3/8", 7/16" and 1/2" and 9/16" open-end wrenches
- 5/32", 3/16" and 7/32" Allen wrenches or drivers.
- Power hand drill and 5/16" drill bit.

S MANUA



