



Kubota ZD1211

(p/n: 1KUBZD1211CK)

Console Kit

INSTALLATION & OWNER'S MANUAL

Service Parts:	
Console Panel	8SV-113-00255
Wire Harness, Console	9SV-WH-00137

Approximate Installation Time *

Experienced Dealer Technician – 15 Mins

Average Dealer Technician – 30 Mins

Do-It-Yourself – 45 Mins

TOOLS REQUIRED:

- Set of Standard and Metric Sockets (3/8" Drive)
- Set of Standard and Metric Open-End Wrenches
- Drill/Driver
- #2 Phillips Head Bit
- Snips

Register your new product quickly online at Curtiscab.com/product-registration/



Curtis encourages all customers to register their Curtis products. However, failure to do so will not diminish right to warranty. Curtis Industries does not sell or share your information with anyone else.

Download a digital copy of your installation instructions online at Curtiscab.com/literature/



Curtis strives to continuously improve our products, technical documentation, etc. Therefore, the installation manual for this product may have been updated after your product was packaged. The latest revision of the installation manual can always be found at the website above.

The contents of this envelope are the property of the owner. Leave with the owner when installation is complete.

Rev. A, 06/15/2021

p/n: IM-1KUBZD1211CK

ACCESSORY INSTALLATION

Step 1: (Vehicle Prep)

- 1.1 Remove the battery cover and disconnect the negative battery terminal.
- 1.2 Locate the wire harness in the console kit and connect the ring terminal on the end of the red wire to the positive battery terminal.
- 1.3 Add the ring terminal on the black wire to the screw installed on the ground terminal, but leave disconnected from the battery at this time.
- 1.4 Cable tie the relay to the vehicle as shown with the wires aiming downwards to shed water.

Hardware Used	Qty
8" cable tie (thin)	1

- 1.5 Cable tie the fuse holder to the vehicle as shown with the wires aiming downwards.

Hardware Used	Qty
8" cable tie (thin)	1

- 1.6 Locate the purple wire with the male bullet terminal on the end and route forward along the cab wire harness and under the seat to the vehicle signal wire location.
- 1.7 Disconnect the yellow wire from the cab wire harness and connect the male bullet terminal on the purple wire from the console harness in its place.
- 1.8 Connect the yellow wire from the cab wire harness to the female bullet terminal on the pigtail wire.
- 1.9 Secure the purple wire to the cab wire harness to prevent the wires from touching any hot or sharp objects.

Hardware Used	Qty
8" cable tie (thin)	6

- 1.10 Route remaining section of wire harness up from the battery box and forward under the ROPS to the right rear of the cab.

Hardware Used	Qty
8" cable tie (thin)	6

- 1.11 Peel back the rubber filler in the rear and route the wire harness into the cab and forward to the hinge tube.




Fig. 1.2 (Connect Positive Wire)




Fig. 1.6 (Connect Signal Wire)




Fig. 1.10 (Route Wire Into Cab)




Fig. 1.11 (Route Wire Into Cab)

ACCESSORY INSTALLATION

- 1.12 Route the harness up the hinge tube and forward through the hole in the tube at the top of the window.
- 1.13 Route the harness forward along the door header and over to roughly the center of the windshield.



Fig. 1.12 (Route Harness up Hinge Tube)

- 1.14 Install the supplied cable ties through the threaded inserts in the windshield support and hang the console as shown

Hardware Used
8" cable ties (thin)

Qty
2




Fig. 1.14 (Hang Console Panel)

- 1.15 Connect the push-on terminal on the black wire to the grounding pad riveted to the inside of the console panel.

- 1.16 Leave the red wire loose at this time.




Fig. 1.15 (Connect Ground Wire)

- 1.17 Loosely install cable ties along the right door header to secure the harness.

Hardware Used
8" cable ties (heavy duty)

Qty
3

- 1.18 Pull enough harness forward into the console to ensure that it will not be too tight when the console is in position.



Fig. 1.17 (Secure Wire to Door Header)

ACCESSORY INSTALLATION

- 1.19 Install p-clamps down the hinge tube to secure the wire harness as shown.

<u>Hardware Used</u>	<u>Qty</u>
1/2" P-Clamp	4
#10x3/4" Self Drill/Tap Screw	4



Fig. 1.19 (Install P-Clamps)

- 1.20 Route the harness along the bottom of the sideframe and re-install the rubber filler over the harness as shown.

- 1.21 Continue installing the remaining accessories at this time.

Install the wiper/washer kit first.



Fig. 1.20 (Run Wire out Under Rubber Filler)

Step 2: (Install Console)

- 2.1 Once all accessories are wired to the console, re-connect the negative battery terminal and test functionality of each of the accessories. Make any required adjustments.
- 2.2 Support the console and cut the two cable ties holding it.
- 2.3 Loosely secure the console along the bottom. Begin the thread engagement by hand to avoid cross threading.

<u>Hardware Used</u>	<u>Qty</u>
1/4-20x5/8 Bolt	4

- 2.4 Connect the ends of the console to the door header and tighten all fasteners.

<u>Hardware Used</u>	<u>Qty</u>
1/4-20x5/8 Bolt	2
1/4-20 Locknut	2

- 2.5 Re-install battery cover.




Fig. 2.3 (Install Fasteners Along Underside)



Fig. 2.4 (Install Fasteners Into Sides)